

ST1821

Configuration Control SC



Configuration Control SC for production, assembling and test of blinds. The control of the blinds is operated via the data wire of the blind.

Offers the basic functions of the CTS Software (Configuration Tool Software for Blinds) without Notebook/PC.

Functions:

- Move- and tilt control
- Fast movement
- Referencing end-limits of blind
- Transport position

For operation one additional ST1811 is required.

Technical Features:

- 7 Control push buttons
- Display 2x8 character
- for 1 blind
- incl. 5m Connection Cable to ST1811



| Description | Order No. |
|--------------------------|-----------|
| Configuration Control SC | ST1821 |